



1854640

Hobart Accent Table

Parts and Hardware List

A.	Top Assembly	1 pc
B.	Legs	4 pcs
C.	Shelf	1 pc
D.	Drawer Stoppers	4 pcs
E.	Phillips Head Screws	4 pcs
F.	Allen Head Bolts	4 pcs
G.	Lock Washers	4 pcs
H.	Flat Washers	4 pcs
I.	Allen Head Wrench	1 pc
J.	Phillips Head Screwdriver	1 pc

- * Please make sure that you have all the parts and hardware indicated above before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.


Hardware Illustrations



D. Drawer Stopper




E. Phillips Head Screw



F. Allen Head Bolt



G. Lock Washer



H. Flat Washer



1854640

Hobart Accent Table

Attach Shelf and Leg

1. **Attach Shelf (C)** Align the pre-drilled holes in the Shelf (C) with the pre-drilled holes in the pre-cut grooves of Legs (B). Secure with Phillips Head Screws (E) using Phillips Head Screwdriver (J). See Illustration #1.
2. **Attach Legs (B)** Remove the drawer from Top Assembly (A). Align the pre-threaded holes in the Legs (B) with the pre-drilled holes in the bottom of Top Assembly (A). Secure with Allen Head Bolts (F), Lock Washers (G) and Flat Washers (H) using Allen Head Wrench (I). See Illustration #1.




Illustration #1

3. **Attach Drawer Stoppers (D)** Partially insert the drawer into the Top Assembly (A). Insert the Drawer Stopper (D) into the pre-drilled holes in the side panels of drawers. See Illustration #2.




Illustration #2